

Cable Taping Standards

- Arrange the cables in an organized fashion before taping. Do not pile cables on top of each other



- Attach a few small pieces of tape along the entire cable run to secure the cables in place. Then run a piece of tape directly down the center



- Run a piece of tape along each side of the centered piece of tape to cover the entire width of the cable run. If you have a wide area to cover, repeat this until completely covered



- Once the cable width is covered, attach a few pieces of spike tape to ensure people are able to see it in low light. The finished product should look like the image below

